用户手册_NT24111_多国语言 尺寸：76.5*110mm 62g 42P UPM哑粉 骑马钉

反面空白页

NOTHING (R)

phone (3a) / phone (3a) Pro

MODEL: A059/A059P

Trademarks and Permissions

The Bluetooth® word mark and logo are registered trademarks owned by Bluetooth SIG, Inc.

qualcomm is a trademark of Google Inc, LTD is a trademark of Google Inc.

The N-Mark is a trademark or registered trademark of NFC Forum, Inc. in the United States, and other countries.

Other trademarks, product, service, and company names mentioned may be claimed by their respective owners.

Privacy Policy

NOTHING is constantly striving to protect your personal information and privacy. Learn more about this by following steps: Settings > Privacy > Privacy Policy.

Regulatory Label

View regulatory labels by following steps: Settings > About Phone > Regulatory Labels.

Precautions for using the device

Please read the following guidelines carefully before using to ensure safe and proper operation. Additional guidelines are found at https://nothing.tech.

Do not attempt to remove or replace the battery by yourself which may damage the battery and device, and cause short circuit, overheating, fire, and injuries.

Do not use the device if it is cracked or damaged, stop using immediately, and contact customer support.

Use approved chargers, data cables, batteries, and other accessories. Using unapproved ones may potentially block, shock, fire, explosion, or other hazards.

The charger shall be installed near the socket-outlet, and shall be easily accessible during the charging when in use.

Do not use the charger when the charger cord is damaged or the electric shock hazard.

Keep the device out of reach of children. To avoid choking, or any other hazards, do not allow children to play with small accessories.

Ideal temperature: 0°C to 35°C for operating, -20°C to 45°C for storage.

Avoid using the device in dusty, damp, or dirty environments, or near sources of magnetic interference.

Keep a minimum distance of 15 cm between a wireless device and an electronic implant (pacemaker, insulin pumps, neurostimulators, etc.) to avoid potential interference. If implant, hold the device on the side opposite the implant.

The device may not be safe for those with epilepsy and other conditions that cause photosensitivity, please consult your doctor before using the device.

Do not use the device when you are driving. Be sure to obey all laws and regulations while driving.

Please check all laws and regulations when using the device, especially in hospital or medical institutions, schools, gas stations, aircraft, and areas with explosive hazards.

Keep the device away from the belly of pregnant women and lower abdomen of adolescents.

Children and adolescents should make reasonable use of the device and take breaks to avoid any impact on vision or excessive duration of calls.

Do not use the device beside hearing damage, do not listen at high volume levels for long periods.

Keep the device and battery away from excessive heat and direct sunlight, such as in a car, on or in heating equipment, or in microwave ovens. Battery may explode if overheated.

Do not expose the device to liquids, moisture, or rain. The device is splash, water, and dust resistant (IP54 rating), but not waterproof.

A battery subjected to extremely low air pressure may result in an explosion, or the leakage of flammable liquid or gas.

Do not dispose of the device in fire, it may explode. Dispose of the device according to local regulations. Do not dispose of the battery as it could explode.

Do not pierce, bend, or deform the device. In the event of any of these occurrences, avoid using the device, as internal damage may occur.

All batteries have a limited number of charge cycles before they need to be replaced. Battery charging cycles may be affected by the following factors: usage patterns, network configuration, and how 5G works in your location and other factors.

Do not expose the device to extreme cold or heat. Operating the device in environments outside the recommended temperature range may damage the device or battery, or cause it to fail.

Do not attempt to modify or tamper with the device, including inserting foreign objects, immersing in water or other liquids, exposing to excessive external pressure, puncturing, or disassembling. Doing so voids the warranty.

Do not use the device if the screen is broken or damaged, stop using immediately, and contact customer support.

Do not use the device if the battery is swollen, stop using immediately, and contact customer support.

Do not use the device if it is overheating, stop using immediately, and contact customer support.

Do not use the device if liquid is detected, stop using immediately, and contact customer support.

Do not use the device if the charging port is damaged, stop using immediately, and contact customer support.

Do not use the device if the camera lens is damaged, stop using immediately, and contact customer support.

Do not use the device if the fingerprint sensor is damaged, stop using immediately, and contact customer support.

Do not use the device if the speaker is damaged, stop using immediately, and contact customer support.

Do not use the device if the microphone is damaged, stop using immediately, and contact customer support.

Do not use the device if the SIM card tray is damaged, stop using immediately, and contact customer support.

Do not use the device if the USB port is damaged, stop using immediately, and contact customer support.

Do not use the device if the antenna is damaged, stop using immediately, and contact customer support.

Do not use the device if the display is damaged, stop using immediately, and contact customer support.

Do not use the device if the battery is damaged, stop using immediately, and contact customer support.

Do not use the device if the charging cable is damaged, stop using immediately, and contact customer support.

Do not use the device if the charging adapter